

Using Ferris® File-A-Wax Blocks & Slices

Ferris® File-A-Wax is available in five formulations to accommodate your widest range of design needs. It can be easily carved, shaped and even machined to reproduce the most intricate of design details. In order to facilitate the design process, File-A-Wax is available in a wide range of shapes and forms.

Step 1: Calipers are used to measure where the cut should be made to accommodate both the finished size of the piece and additional space for shaping, etc.



Step 3: A broad faced file is used to roughly size the cut piece of File-A-Wax into the general shape of the finished piece.



Step 2: The block is cut using a jewelers saw.



Step 4: Calipers are used to double check the overall dimensions of the roughly shaped piece.





How-To:

Using Ferris® File-A-Wax Blocks & Slices cont.

Step 5: A sizing ring is placed over the rough cut piece of File-A-Wax. The hole is scribed onto the wax.



Step 7: Creating the finish design can be done using a wide variety of power or hand operated shaping & carving tools.



Step 9: The stone is test fit in the bezel to check rough seating, positioning and overall design aesthetics.



Step 6: The hole is cut into the File-A-Wax piece using a motor tool. This can also be done with a carving knife.



Step 8: Shaping a properly sized bezel can be also accomplished using a wide range of power or hand tools.



Step 10: A wire wax is attached to the finished wax design to ready the piece for casting or to make a model.

